

AURAE TECHNICAL DATA SHEET





PLAN VIEW

Configuration and layout:

- The louvre blades can be set at any centres.
- Blade angle can be set at any degree of pitch between completly flat and 90° vertical.
- Once the degree of pitch has been decided upon and the louvres are installed, the angle of the blades is fixed and cannot be changed.

Assembly and Installation:

• The louvre blades are fixed to the side channels with stainless 10gx19 self-tapping screws.

• The size of the side channel can be varied to suit individual project requirements. If required, the channel can be substituted for an aluminium flat bar, angle or box section.

Structural Requirements:

• The length of the louvre blade must be within the span appropriate to the wind loading on the louvre blade. See Span Data Table for spans relative to wind zones.

• The fixing detail of the side channel to the main support structure varies dependent on the type of structure. Contact Insol for project specific recommendations.

Componentry and Finishes:

• All the aluminium components (the louvre blade, end caps and side channel) can be finished with any exterior powder coat or grade of anodising.

• Any louvre blades that are too wide to be covered by the side channel are

• If the louvre blade can fit within the width of the side channel (i.e. if a side